

INSTRUCTIONS FOR SPEED RING 9500

Fits Lowel DP



CAUTION: THE DP SAFETY SCREEN MUST BE USED WITH THIS LIGHT FIXTURE/SPEED RING COMBINATION.

Mounting the Speed Ring to the Light:

- 1- Attach the safety screen to the DP light.
- 2- Loosen all brass thumbscrews and remove all four capture plates.
- 3- With the Speed Ring oriented so that the plates will be facing into the lightbank, slide the Speed ring past the flange on the front of the light housing.
- 4- Replace the capture plates, while squeezing the latch firmly against the Speed ring between your thumb and forefinger, re-tighten the thumbscrews.

Parts list:

1	95051000	All metal Speed Ring
4	95002000	DP capture plates
8	95005000	8-32 x 1/2" thumbscrews