

# INSTRUCTIONS FOR SPEED RING 9505

Fits Lowel DP and DP Daylight (HMI)

**CAUTION:** THE DP SAFETY SCREEN OR DP DAYLIGHT SAFETY GLASS MUST BE USED WITH THIS LIGHT FIXTURE/SPEED RING COMBINATION.

## Mounting the Speed Ring to the Light:

- 1- Attach the safety screen to the DP light or the safety glass to the DP Daylight.
- 2- Loosen all brass thumbscrews by approximately ¼" and rotate all latches to the open position.
- 3- With the Speed Ring oriented so that the latches are facing toward back of the light, slide the Speed Ring past the flange on the front of the light housing. (See Photo 1.)
- 4- Rotate the latches to the closed position and, while squeezing the latch firmly against the Speed Ring between your thumb and forefinger, re-tighten the thumbscrews. (See Photo 2.)
- 5- When assembled, the ring should appear as shown in Photo 3.



Photo 1



Photo 2



Photo 3

## Parts list:

1	95051000	All metal Speed Ring
4	95002500	DP latches
4	95005000	8-32 x ½" thumbscrews
4	95005100	8-32 x ¾" flat Phillips-head screws

**CHIMERA** 1812 Valtec Lane, Boulder CO 80301 303-444-8000 888-444-1812 fax 303-444-8303 sales@chimeralighting.com